

### **GY-HM170/190/200 Firmware Update Procedure:**

To prepare update SD card:

1. Uncompress the downloaded firmware file.
2. Copy the entire folder PRIVATE to a blank SD CARD.

To enter update mode:

1. Attach the battery and connect DC Power supply. Both must be connected to enter update mode.
2. In power OFF condition, press and hold MODE and ZEBRA/5 buttons together.
3. Slide power switch to ON position. Keep holding down buttons until FIRMWARE UPDATE screen appears on the LCD monitor. Release buttons. See attached picture.



4. Follow instruction of inserting SD card in SLOT B.
5. Update automatically starts showing progress bar.
6. When finished, LCD monitor indicates FIRMWARE UPDATE COMPLETED.
7. Remove SD card. Detach battery and unplug power source.
8. Reconnect power source. Perform RESET ALL from Main Menu>System>Reset All>Reset.
9. Select preferred OSD language.