

How to update firmware of KY-PZ100

■ Preparations

- KY-PZ100 unit
- AC Adapter (KY-PZ100) or PoE+ HUB
- PC (Connecting with internet to download firmware from JVC web site, installed Decompression software for Zip file)
- Equipments to build local area connection , HUB ,LAN cable etc

■ Preperation for update

- Download the updating firmware from the URL ***
URL: *****
- Decompress Zip file
- Put the firmware to local folder


■ Note

- Do not remove Power cable or LAN cable during updating
- Updating time Approx. 2 min

■ How to Update


Updating of KY-PZ100 should be done with Setting Screen on PC via network.

1. Connect PC to network of KY-PZ100. Updating software is done unit by unit.
 2. Key in IP adress of camera on URL address bar of web browser
- * Default value 192.168.0.10




* In case of switching HUB connection , Use LAN straght cable.


1. Click ' Maintenance ' button on Web Setting Screen
2. Click ' Change ' on Dialog screen changing maintenance mode
3. Shown correct version of firmware
4. Click ' Firmware Update '
5. Click ' Choose File ' and select new update firmware ' PZ100_V0101-0000.UPD '




• Click ' Update ' and shown Check dialog screen , and then click ' OK '




• Shown progress bar during Updating



• Shown complete dialog , and Clock 'OK ' button. And Reboot KY-PZ100



• No operation during rebooting for approx. 30 sec



Please confirm new software version from meantenace screen after rebooting.