

## RM-LP100 Firmware update procedure

[RM-LP100 Firmware update procedure]

1. Execute format the USB memory by FAT32. RM-LP100 does not recognize the USB memory other than FAT32 format.
2. Copy the firmware file(\*.bin) to the root folder of the USB memory.
3. Connect the USB memory to SERVICE terminal of RM-LP100.



4. Turn on the POWER switch with holding down "USER1" and "USER2" buttons.



5. Keep holding down the buttons until the "USB Firmware Update Mode" screen appears.



6. Check the displayed firmware version is the same as the version which was written the USB memory.
7. Push "Update" button.
8. Push "OK", then firmware update will start.
9. Firmware update will be completed automatically then turn off and reboot the RM-LP100.

[ RM-LP100 Firmware version checking procedure]

1. Turn on the POWER Switch while holding down "USER1" and "W" (ZOOM Switch).
2. Keep holding down the buttons until the "ADJUSTMENT MODE" screen appears.
3. Push "Status Display" button. "STATUS DISPLAY" Screen will appear.
4. Version number is shown on the display.
5. Push "RETURN" button, then push "Exit" button.
6. Turn off the POWER switch.

