Read me first / Orientation and setup



For support please contact:

- USA: http://pro.jvc.com/prof/support/index.jsp
- EMEA: Please contact the local dealers in your area
- JAPAN: info\_sis@jvckenwood.com

Page 1 of 6 / Read Me First All information in this document is confidential and subject to change without notice. © JVCKENWOOD Corporation 2019, All rights reserved.

### **EXTERNAL FEATURES**

#### FRONT PANEL




#### FRONT PANEL DETAIL

- 1. USB connectors
- 2. Restart LED indicator
- 3. Disc activity LED indicator
- 4. System ON/OFF LED Indicator
- 5. Network activity LED Indicators
- 6. System On/Off button



#### **BACK PANEL**



1. 3x Dual HD-SDI input

with mini HD-SDI loopback each

- 2. HD-SDI + HDMI PGM output
- 3. DVI output
- 4a. DP (Display Port) output
- 4b. HDMI output
- 5. Motherboard Audio In/Out connectors
- 6. 1x USB 3.1 port and USB C port
- 7. 4x USB 3.0 port
- 8. RJ45 100 / 1000 Mbps Ethernet port
- 9. 2x USB 2.0 port

#### NOTE:

The order and position of cards can differ according to the configuration of your system.





### SETUP

- 1. Unpack and place the CONNECTED CAM STUDIO system on a flat surface.
- 2. To mount the system in a rack housing use the brackets on the sides.
- When the system is placed at the desired location, plug in the provided power cord into the rear socket of the power supply. Plug the power cord into an AC power supply.
- 4. Connect the external keyboard and mouse to the USB ports.
- 5. Connect the HD-SDI / HDMI inputs to cameras.

- 6. Connect the Ethernet cable for Internet access.
- 7. Connect a power cable to the power outlet.
- Power ON the unit with the switch located on the front panel.
  Your CONNECTED CAM STUDIO will boot the operating system.

For instructions on the operation of the Connected Cam Software please refer to the CONNECTED CAM STUDIO SW users operating manual.

### **OVERVIEW OF SYSTEM CONFIGURATION**

#### NOTE:

Windows operating systems do not require a password to log in the first time.

You will need to gather some information prior to configuring your CONNECTED CAM STUDIO. You may need some help from your system administrator in assembling this. You need to perform the following tasks:

- Assign a host name and obtain an Internet Protocol (IP) address
- Set your own time zone
- Set a password for the superuser (root) account
- Create user accounts
- Provide network configuration information

For instructions on how to assign a host name, obtain an IP address and the other tasks, please talk to your systems administrator or refer to the documentation for the operating system.



### REPACKAGING FOR TRANSPORT BY AIR / MAIL

When shipping your unit to another destination or returning for service, you will need to repackage it prior to transporting it to its destination. Please save all the packaging that comes with the CONNECTED CAM STUDIO including the styrofoam and the cardboard box that protects it from damage due to getting bumped or dropped while in transit.

- 1. Put the unit inside the plastic wrap that came with it.
- 2. Slide the styrofoam end-pieces on the sides a place the unit inside the box as shown.
- 3. Place all documentation, including this Read Me First document, and all the cables into the smaller box above the unit in the box as shown.
- 4. Seal the cardboard box with heavy sealing tape and label it.



